

## LuxPro LP139 Keychain Light

### Operation Instructions

On/Off: Press and release the button on the tail cap to turn the light on and off.



Glow-In-The-Dark: Flashlight must be exposed to a bright light for a few minutes to activate the glowing rubber feature. Duration of glow varies by color of light and ranges between 2-5 minutes.

### Battery Replacement




The LP139 uses 4 LR44 batteries.

To replace the batteries, turn the tail cap counterclockwise to remove it. Tip the light downward to slide out the plastic casing which contains the batteries. Once the battery case is free, the old batteries can be pushed out and new batteries can be inserted. For best results, we recommend using brand new alkaline batteries that are the same voltage and brand. The use of the plastic casing is not required for the batteries to work but does allow for easier insertion of the batteries back into the light. Place the batteries in the light with the (+) side facing up. Re-attach the tail cap by pressing down lightly and turning it clockwise until tight.



If you know it will be a while between uses, we suggest removing the batteries from the flashlight and storing it in a dry, protected place.

### Performance Specs

ANSI/PLATO FL1 STANDARD			
			
MODES	LUMENS	RUN TIME	BEAM DISTANCE
High	25lm	1h	12m